

Day 1 Electrician — Field Guide

Describes Lumina app version 2.5.10+89.

Audience: Electricians running Day 1 wiring prep on a Lumina installation.

Log in, read the blueprint, do the work, check out clean so Day 2 can finish. That's the job.

What you'll need

- Your 4-digit **Installer PIN** (dealer code + installer code)
 - The Lumina app on your phone
 - Your materials — wire, power supplies, injection connectors, brackets (exactly what's on the blueprint materials list)
 - Your standard electrical tools
 - Phone signal or Wi-Fi at the job site (for checking off tasks)
-

1. Log in

Day 1 happens inside **Installer Mode**, gated by a 4-digit PIN.

PIN format

- Digits 1–2: your **dealer code** (e.g., 42)
- Digits 3–4: your **installer code** (e.g., 07)
- Together: 4207

You got this from your dealer admin at onboarding.

Steps

1. Open the Lumina app
2. Tap the **Lumina logo** 5 times on the login screen — **all five taps within 3 seconds**, or the count resets.
There's no visual feedback until the Staff PIN screen opens on tap 5.
3. Type your 4-digit PIN
4. The app verifies against your dealer's records and drops you into Installer Mode

Session timeout

- Sessions run **30 minutes** of activity
 - Warning pops **5 minutes before** it ends — tap anything to extend
 - If you get logged out, sign back in. Your work is saved.
-

2. Open the Day 1 Queue

From the Installer Landing screen, tap **Day 1 Queue**.

What's in the queue

Every job for your dealer that's ready for pre-wire:

- **Signed** (cyan badge) — customer signed, Day 1 not yet scheduled
- **Pre-wire scheduled** (amber badge) — Day 1 date locked in

Newest jobs at the top.

Card fields

Element	Meaning
Customer name	Who the job is for
Address	Full street, city, state, zip
Status badge	Cyan = Signed, amber = Pre-wire scheduled
Day 1: {date}	Shown only if Day 1 is scheduled
Reschedule	Inline button next to the date
Schedule Day 1	Shown only if Day 1 hasn't been scheduled yet

3. Schedule Day 1

For any **Signed** job that's not yet scheduled:

1. Tap **Schedule Day 1** on the card
2. Pick the date you'll be on-site (today → 365 days out)
3. Tap **OK**
4. Snackbar confirms: "**Day 1 scheduled for {date}**"

Job moves from **Signed** to **Pre-wire scheduled**. Customer gets an SMS confirming the date immediately, plus a reminder SMS the night before.

To change a date: tap **Reschedule** next to the existing date, pick a new one.

4. The Day 1 Blueprint screen

Tap any job card to open its **Day 1 Blueprint**. Everything you need is on one scroll.

Section 1 — Home photo with channel overlays

- Front-of-home photo with colored polylines for each channel run
- Tap the photo to expand full-screen
- **Channel chips** below — tap to highlight that run on the overlay

Use this to orient before you start running wire.

Section 2 — Controller mount

Where the controller goes.

- **Location description** — specific text like "Garage left interior wall, 3 feet from breaker panel." This is what the salesperson promised the customer.
- **Mount photo** — if captured
- **Mount type** — Interior or exterior

All wiring runs back to this point. Mount the controller box first.

Section 3 — Per-channel detail cards

For every channel:

Field	What you need to know
Channel number + label	Header — "Channel 1 — Front Roofline"
Linear footage	Total length of the run
Run direction	Which way Day 2 will feed the strip (L→R, etc.)
Start description + photo	Where the run begins
End description + photo	Where the run ends
Injection points list	Every power injection point on this run

Injection points

For each one:

- **Location description** — where on the run (e.g., "Corner of deck behind downspout")
- **Distance from start** — feet from the beginning of the run
- **Wire gauge** — recommended size based on distance from controller:
 - **Direct** (0 ft) — connector only
 - **14/2** — up to 30 ft
 - **12/2** — up to 90 ft
 - **10/2** — up to 140 ft
 - **EXCEEDS 140ft** — stop, call your dealer admin
- **Photo** — if captured

Section 4 — Materials list

Power and hardware only on Day 1 — wire, power supplies, injection connectors, mounting brackets.

LED strip is NOT delivered on Day 1. It arrives with the Day 2 install team. Day 1 is wiring prep only.

Each row shows item name, category (POWER or HARDWARE), and quantity needed.

Bring exactly what's on the list. Short on anything? Call your dealer admin before you arrive.

Section 5 — Task checklist

Auto-generated list of every action you need to perform. Grouped by type:

- **Mount the controller** — one task
- **Wiring tasks** — one per channel, e.g., "Run wire through left corner of house to right corner above garage — 120ft"
- **Injection tasks** — one per injection point, e.g., "Cap and label at corner of deck, 60ft"
- **Verification task** — "Verify all wires are accessible outside wall for Day 2"

Tap a checkbox as you complete work. Green check appears.

Progress shows as "**X of N tasks completed**" with a progress bar — cyan while working, green at 100%.

5. Do the work

Standard Day 1 sequence:

1. **Arrive on-site.** Greet the customer. Confirm gate codes, dogs, parking from the salesperson notes (visible on the Job Detail screen).
2. **Mount the controller** at the specified location. Check the task.
3. **Run wire from the controller out to each channel start point**, then along the channel path to the end. Use the start/end descriptions and the channel polyline as your guide.
4. **At each injection point**, run a separate dedicated wire from the controller (or a power supply mount) and **cap and label** it clearly. Labels match channel number + injection number.
5. **Every wire end must be accessible outside the wall.** Day 2 needs to grab wires and connect them to the LED strip — they can't be inside the wall, behind sheetrock, or hidden behind eaves.
6. **Check tasks off as you go.**

***The Day 1 rule:** Every wire — controller, channel, injection — must be accessible outside the wall before you check out. Miss this, and Day 2 has to cut into walls.*

6. Mark Day 1 complete

When every task is checked, **Mark Day 1 complete** turns green.

Check-out is blocked until all tasks are checked

- Any unchecked task → button disabled, reads "**Complete all tasks to mark complete**"
- The "Verify all wires are accessible outside wall for Day 2" task is in this list. You can't check out without confirming it.

Check out

1. Tap **Mark Day 1 complete**
 2. Confirmation dialog asks for your name (or installer code)
 3. Type it and tap **Confirm**
 4. The app updates the job:
 - Status: **Pre-wire scheduled** → **Pre-wire complete**
 - Your name recorded as Day 1 tech
 - Completion timestamp saved
 5. Snackbar: "**Day 1 complete! Job ready for Day 2.**"
 6. You're back in the Day 1 Queue. The job has moved to the Day 2 team's queue.
-

7. What the customer gets

The instant you mark Day 1 complete, the customer gets an SMS:

"Great news, {first name}! Wiring prep is complete at your home. Your light installation day is coming soon — we'll text you the night before. — {dealer sign-off}"

Sent automatically. Don't send anything manually.

Standard reminder SMS goes out the night before Day 2, once Day 2 is scheduled.

8. Critical Day 1 rules

Break these and Day 2 fails:

Rule	Why
Every wire accessible outside the wall.	Day 2 can't install if they have to cut walls.
Label every injection wire — channel number + position.	Unlabeled wires waste hours.
Mount the controller exactly where the blueprint says.	The customer agreed to that location. Moving it means re-quoting.
Use the wire gauge the blueprint lists.	Undersized wire = voltage drop, dim or off-color LEDs at the end of the run.
Don't skip the "verify wires accessible" task.	Walk the job and physically touch every wire end before you tap it.
Bring exactly the materials on the list.	Day 1 is wiring only. LED strip arrives on Day 2.
Check off tasks as you go, not at the end.	If you're interrupted, the next person knows where you left off.

What success looks like

- Controller mounted at the exact blueprint location
- Every channel wire run from controller to start, along the path, to the end
- Every injection wire capped and labeled with channel number and position
- Every wire end accessible outside the wall (you physically touched each one)
- Every task in the checklist checked
- **Mark Day 1 complete** tapped; job moved to the Day 2 queue
- Customer received the automatic SMS confirming wiring prep is done

If something isn't working

"The job isn't in my queue." Customer hasn't signed yet, or the job is assigned to a different dealer. Confirm with your dealer admin.

"I can't tap Mark Day 1 complete." Some tasks are still unchecked. Scroll up, find the task without a green check, finish it, check it.

"Wire gauge says EXCEEDS 140ft." Stop. Call your dealer admin. The controller location may need to move closer to the run, or a supplemental power supply may be needed mid-run. Don't install with under-rated wire.

"The home photo doesn't match what I see on-site." Landscaping or paint may have changed. Match the channel start/end descriptions to physical features (corners, downspouts) rather than relying only on the photo.

"I forgot to schedule Day 1 before showing up." Open the Day 1 Queue, find the job, tap **Schedule Day 1**, pick today. The customer gets the SMS automatically.

"I need to leave the job partially done." Check off only the tasks you actually completed. **Do not** mark Day 1 complete. Job stays in **Pre-wire scheduled**. You or another electrician picks it up next visit.

"PIN won't work." Confirm all 4 digits. If you've been locked out after 5 failed attempts, wait 30 seconds or dismiss and reopen the Staff PIN screen. If it still won't work, your dealer admin needs to confirm your installer account is active.

Need help? Call your dealer admin or your Nex-Gen LED LLC corporate contact.

Describes Lumina app version 2.5.10+89 — August 2026